


4 DRUM SPILL PALLET

Spill Pallets Precautions For Use:

- The overall inspection should be performed before use, including whether the drain is loose and whether the black grating can be completely placed inside the spill pallet.
- When transferring drums(containers) and pallets as a whole, the drums(containers) should be secured with elastic bands to prevent slipping off the pallets.



SPECIFICATION			
Model No	ZC5		
DIMENSION	1300*1300*300mm		
Static Load	3000KG	Dynamic Load	1300KG
MATERIAL	PE		
CAPACITY	280L / 74 US gal		
WEIGHT	30.6KG		
FUNCTION	ELECTRIC FORKLIFTS PALLET JACKS		

