

2 DRUM SPILL PALLET

Spill Pallets Precautions For Use:

- The overall inspection should be performed before use, including whether the drain is loose and whether the black grating can be completely placed inside the spill pallet.
- When transferring drums(containers) and pallets as a whole, the drums(containers) should be secured with elastic bands to prevent slipping off the pallets.



SPECIFICATION			
Model No	ZB5		
DIMENSION	1300*680*300mm		
Static Load	1200KG	Dynamic Load	600KG
MATERIAL	PE		
CAPACITY	150L / 40 US gal		
WEIGHT	15.1KG		
FUNCTION	ELECTRIC FORKLIFTS PALLET JACKS		

